



WATERPROOF THERMOMETER



Operating Instructions

INSTRUMENT OPERATION - The instrument is switched on by pressing the ON/OFF button located on the front of the instrument. Insert the probe into the substance being measured. The instrument reading may take a few seconds to stabilise, depending on the nature of the measurement.

MAX/MIN - Press the MAX/MIN button to display the maximum reading (MAX symbol displayed). Press the MAX/MIN button again to display the minimum reading (MIN symbol displayed). Press MAX/MIN button again to return to normal readings. Press the reset button on the rear of the instrument to reset minimum and maximum temperature memory.


Please note: Max/Min readings are not saved so switching the thermometer off will clear the max/min readings.

°C/°F - Press the °C/°F button on the rear of the instrument to switch between Centigrade and Fahrenheit.

BATTERY REPLACEMENT - Low Battery icon will flash at low power and then turn off. Replace the battery immediately when 'Bat' is displayed, using a CR2032 battery or 3V equivalent. The battery is located under the battery cover at the rear of the instrument.

BATTERY WARNING: KEEP OUT OF REACH OF CHILDREN.

If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.



EMC/RFI - Instrument performance may be affected if operated within a high frequency radio field, such as near a mobile phone, or if subjected to an electrostatic shock.

GUARANTEE - This instrument carries a one-year guarantee against defects in either components or workmanship. During this period, products that prove to be defective will, at the discretion of ETI, be either repaired or replaced without charge. The product guarantee does not cover damage caused by fair wear and tear, abnormal storage conditions, incorrect use, accidental misuse, abuse, neglect, misapplication or modification. Full details of liability are available within ETI's Terms & Conditions of Sale at etiltld.com. In line with our policy of continuous development, we reserve the right to amend our product specification without prior notice.



Supplied by
Electronic Temperature Instruments Ltd
Worthing · West Sussex · BN14 8HQ
01903 202151 · sales@etiltld.com · etiltld.com



810-275/17.09.25